

CableMaster™ 800 Plus

Consumable Selection Guide

CableMaster™ Consumables	Application Type										
	Fire & Service Cabling	Metal/Nylon Straps	Metal Pipes	Small Diameter Rigid Pipes	Cable Fixing	Electrical Conduit	Catenary Wire	Flexible/Plastic Pipe	Light Duty Cable Tray	Strap, Plates & Fixtures	Data Cable
 CableMaster™ Consumables											
 ClipElec™	✓	✓	✓	✓	✓	✓	✓	✓			
 DataLec™ Clip	✓	✓	✓	✓	✓	✓	✓	✓			✓
 CTClip™	✓	✓	✓	✓	✓	✓	✓	✓			
 Threaded Rod Hanger			✓	✓			✓	✓			
 Direct Alignment Half Saddle		✓	✓		✓						
 Strap & Plate Mounting Washer										✓	
 Catenary Wire Bracket					✓		✓				

✓ Recommended



Pulsalift™ 800 Plus
Pole System to suit
CableMaster™ 800 Plus

AUSTRALIA

Sales, Orders and Enquiries

Tel: 1300 780 063

Fax: 1300 780 064

Email: enquiry@ramset.com.au

Web: www.ramset.com.au

NEW ZEALAND

Sales, Orders and Enquiries

Tel: 0800 RAMSET (726738)

Fax: 09 444 2864

Email: info@ramseteid.co.nz

Web: www.ramset.co.nz

PulsaLift™ 800 Plus Pole System



Use your CableMaster™ 800 Plus with the flexible Plusa Lift Plus pole system for complete overhead installation without the need for scissor lift equipment.

- Permanent cable suspension to concrete & steel.
- Pipe suspension to concrete & steel.
- Fire & security cabling.
- Temporary cable suspension.

INSTALLATION

The PulsaLift™ 800 Plus cradle consists of 2 elements: the cup and the retaining bolt (tethered to the cup with a steel cable).



Place the back of the tool (black cap first) into the cup. Make sure that the tool is fully seated.

Press the button of the retaining bolt (to disengage the ball bearings) and push the retaining bolt through the holes in the cage provided over the trigger. Release the retaining bolt button while making sure that the ball bearings have engaged on the other side of the holes.



Depending upon the application height choose whether the extension pole is required or just the triggering pole.

OPERATION

Load the tool while avoiding holding onto the triggering section of the pole.

Hold the pole and tool vertically upwards.

Push the tool against the work surface to close the fastener guide of the tool.

Using the trigger section of the pole apply more pressure to the work surface to fire the tool.

COMPONENTS		DESCRIPTION
CRADLECM800PLUS		Cradle only (Tool not included)
V4-3		0.9 metre (3 foot) Pole with Trigger
V4-EXT		0.9 metre (3 foot) Extension Pole without Trigger
PL800PLUS		Complete Kit (Tool not included)

SAFETY WARNING

Never hold onto the triggering section of the pole whilst loading clips or fasteners into the tool. Inadvertent activation and a severe hand injury may occur. Only ever fire the tool overhead while using the pole system.

CRADLECM800PLUS is only compatible with the CM800PLUS tool.